

Keyboard

KB-8A81/KM-8A81

KB SERIES : Standard Keyboard
KM SERIES : Multimedia Keyboard



KB-8A81



KM-8A81



Features

- Windows® XP/Vista/7/8 compatible
- Provides 6 Media hot keys (KM Series only)
- PC PS/2 & USB fully compatible
- Designed for enhanced Windows® 95/98/2000 key layout
- High quality membrane tactile key switch available
- Switch reliability : Over 3 millions
- Provides three ACPI power management keys
- Dimension : 441(L) x 149(W) x 22(H) mm
- Slim Type

Packing Information

	Packing	CUFT.	20FT	40FT	40HQ
KB-8A81	30 Pcs/Ctn.	3.01'	10530	22080	24660
KM-8A81	30 Pcs/Ctn.	3.01'	10530	22080	24660

Color of Product



Std. Color-01
Black



Std. Color-02
White



Std. Color-03
Black/Silver

Hot Key Spec

(KB Version Only)

- ☾ Sleep — On computers with a power management program, the "Sleep" Hot Key enables you to : Start your screen saver/ Log off Windows / Shut down Windows.
- ☾ Wake Up — On computers with a power management program, the "Wake up" Hot Key enables you to restore, or wake up your computer.
- ☾ Power — On computers with a power management program, the "Power" Hot Key enables you to : Log off Windows / Shut down Windows.

(KM Version Only)

- ☾ Sleep — On computers with a power management program, the "Sleep" Hot Key enables you to : Start your screen saver/ Log off Windows / Shut down Windows.
- ☾ Wake Up — On computers with a power management program, the "Wake up" Hot Key enables you to restore, or wake up your computer.
- ☾ Power — On computers with a power management program, the "Power" Hot Key enables you to : Log off Windows / Shut down Windows.
- ☾ Web/Home — Press this button to go to the default Home Page.
- ☾ Mail — Press this button to activate the e-mail system.
- ☾ Play/Pause — Press this button to begin playing a CD or a video file (or to restart after pause). During playback press this key to pause the playback, press it again to resume playback on current position.
- ☾ -Volume — Press this button to decrease volume.
- ☾ +Volume — Press this button to increase volume.
- ☾ Mute — Press this button to mute sound. Press it again to resume sound.